

Please read this carefully
before using your AdaptEar™

Operating Manual

AdaptEar™

with LimitEar™ Technology



Setting Sensitivity*

Before using your AdaptEar™ it is important to set the unit's sensitivity to the correct level to match your earpieces to the PMR. The potential for hearing to be damaged comes from both the exposure intensity and exposure duration. Listening at higher levels reduces the safe listening duration, which is normally considered as exposure during any 24 hour period.

The tables show sensitivity switch settings for specific earpiece sensitivities and are arranged by impedance and exposure duration. The sensitivity of earpieces is a measure of the audio level produced for a given signal input level. This is usually specified in units of SPL dB/mW, but sometimes as units of SPL dB/V.

Table 1 must be used where units are SPL dB/mW;

Table 2 must be used where units are SPL dB/V.

Impedance is normally 16 or 32 ohms, although other impedances are available. Only 16 and 32 ohms are covered in these tables.

To Set Sensitivity:

- 1) Having established the units of sensitivity for your earpieces (dB/mW or dB/V), select table 1 or 2.
- 2) Select the row in the selected table for your earpiece's impedance and the expected duration.
- 3) In the selected row find the nearest value to your earpiece's sensitivity; the letter at the top of the column is the setting required.
- 4) Using a 5mm flat bladed screwdriver, align the sensitivity switch with the setting letter.

Table 1 SPL db/mW or dbA/mW

Impedance	Duration	AB		CD		EF	
32R	8 hrs	120	116	112	108	104	100
32R	4 hrs	123	119	115	111	107	103
32R	2 hrs	126	122	118	114	110	106
16R	8 hrs	125	121	117	113	109	105
16R	4 hrs	125	121	117	113	109	105
16R	2 hrs	128	124	120	116	112	108

Table 2 SPL db/V or dbA/V

Impedance	Duration	AB		CD		EF	
32R	8 hrs	135	131	127	123	119	115
32R	5 hrs	138	134	130	126	122	118
32R	2 hrs	141	137	133	129	125	121
16R	8 hrs	140	136	132	128	124	120
16R	5 hrs	143	139	135	131	127	123
16R	2 hrs	146	142	138	134	130	126

Operational Notes

It is normal for the red limit light to flash briefly when the sound source produces momentary loud noises, as this indicates that AdaptEar™ is helping to protect your hearing. If you notice that the red limit light is illuminating frequently then it is indicating that the input level to the AdaptEar™ is too high and you should turn down the volume control on the source device.

If you find that you are having difficulty hearing the sound from your earpieces at the controlled level, then you need to improve your isolation from the ambient noise, either by moving further away from it, or by using custom earpieces that block your hearing canal. If you are only using one earpiece you will find that putting in another earpiece, wearing an earplug or a custom fitted hearing attenuator in the other ear will improve your ability to hear considerably.



Head Office:

Boundary House, Boston Rd
London, W7 2QE

Email: info@limitear.com

Phone: +44(0)845 643 4055

Web: www.limitear.com



Made in U.K.

AdaptEar™

AdaptEar™

Thank you for purchasing an AdaptEar™, with LimitEar™ technology, an adapter to help you safely use a Private Mobile Radio with a variety of sensitive earpieces.

Compatibility*

- AdaptEar™ is supplied with a standard adapter cable with a 3.5mm mono jack plug designed for listen only operation with some PMRs. Please note that some PMRs will require a specific adapter plug or cable.
- AdaptEar™ may not function with some automatic noise cancelling ear pieces.

Use with Speaker-Microphones*

AdaptEar™ can be used for listen and speak operation with a fist microphone if used with the optional AdaptEar™ adapter cable.

Using AdaptEar™*

Before use it is important to set the AdaptEar™ to suit the sensitivity of your ear pieces. Refer to **Setting Sensitivity**

- For listen only operation, connect the AdaptEar™ adapter curly cable's 3.5mm jack plug to your PMR audio output. Plug the adapter cable miniDIN plug into the **Adapter™** socket, aligning its flat with the back of the AdaptEar™ case.

Connect your ear pieces to the **Phones** socket.

- To remove Adapter lead, pull on case of plug - **Do Not** pull on the lead.
- You may also connect a second listen source such as a PMR, an mp3 player or mobile phone to the socket for simultaneous monitoring. Using the source volume control, it will mix at an attenuated level with the primary source. This is a 3.5mm 4-pole jack, allowing some mp3 players* and mobile phones* to work with their compatible ear pieces and remote control facilities.

Warnings*

- **You are advised:** Only use your AdaptEar™ when it has been set to match your particular earpieces.
- Do not adjust the sensitivity of your AdaptEar™ whilst wearing your earpieces.
- The table settings establish the general sound level for typical audio content; we recommend you avoid prolonged exposure to atypical content such as test tones.

* For more information about compatibility of AdaptEar™ with PMRs, ear pieces, speaker-microphones and MP3 Players or performance and settings, please consult your dealer or visit www.limitear.com.

